


How to measure your Vertical Blinds

“Inside” Mount shades are installed inside the window frame.




Width

- Measure the exact width of the inside edges of the window frame from three different places; at the top, middle and bottom to the nearest 1/8". Record the narrowest (smallest) measurement.
- **DO NOT** take off any deductions. The factory will take off necessary deductions for a perfect fit.
 - Inside Mount width deduction = 1/4"
 - Inside Mount depth = 2 3/4"
 - Inside Mount flush depth = 4" with Vanes

Height

- Measure the exact height of the inside edges of the window frame from three different places; at the left, center, and right to the nearest 1/8". Record the longest of the three measurements.
 - Top to bottom ceiling mount fabric deduction = 1 3/4"
 - Additional allowance height deduction = 1/4" for clearance from the floor.

“Outside” Mount shades are installed outside the window frame, covering an area bigger than the window size.



Width

- Measure the exact width to be covered, including the window frame. We recommend adding 2" on each side (4" total overlap) to provide the maximum light gap coverage.
 - Outside wall mount depth = 4"

Height

- Measure the exact width to be covered, including the top edge of molding to the bottom edge. We “recommend” adding 2" on the top for the patio door to provide the maximum light gap coverage and space for wall mount bracket installation.
 - Top to bottom wall mount fabric deduction is 2".
 - Additional allowance height deduction : 1/4" for clearance from the floor.
 - If installing “above” window frame : add 2" (wall mount bracket to height measurement)